

# How to Flat Crimp

1. Thread one 2x2 mm crimp onto your Soft Flex. Next, thread your Soft Flex through the opening of your clasp. Finally, thread the Soft Flex back through the crimp, making a loop that captures the clasp. There must be enough slack in the loop that the clasp can move freely.



2. Using your needle nose pliers (flat inside surface), smash the crimp tightly. It should look like a 2x2 mm square when done properly.

